

How to Get your Foam Tested: Produced Foam Test



Step 1: Choose your testing & service level

Contact us to tell us what kind of testing and what level of service you require.

For produced foam testing we offer two levels of service:

- **Standard Service:** 5-working days turnaround from receipt of sample.
- **Express Service:** 24-hour turnaround from receipt of sample (subject to availability).



Step 2: Collect your samples

For each produced foam test, we require the following samples:

- Foam concentrate: 1 litre
- Produced foam: 1 litre
- Induction water: 1 litre

Samples should be sent in clean, sealed, clearly labelled plastic bottles.



Step 3: Label your samples

To make sure we are testing the correct foam and checking against the relevant parameters, we need certain information to be included on your sample, for example foam type, sample location and foam concentration (%).

Blank labels can be downloaded from our website, and an example can be seen here:

| SAMPLE FOR ANALYSIS: PRODUCED FOAM TEST | | | |
|---|----------------------------------|--|--------------------------------|
| Foam Concentrate | | | |
| SAMPLE REFERENCE NO. (INTERNAL USE ONLY): | ORDER REF./P.O. NO.: 290924A | | |
| COMPANY NAME: ACME LTD | SAMPLE POINT: TANK 1 | | |
| SAMPLE LOCATION: CITY REFINERY | MANUFACTURER: OIL | | |
| DATE OF COLLECTION: 26/09/2024 | | | |
| CONCENTRATION: | | | |
| <input type="checkbox"/> 1% | <input type="checkbox"/> 2% | <input checked="" type="checkbox"/> 3% | <input type="checkbox"/> 6% |
| <input type="checkbox"/> 1x1% | <input type="checkbox"/> 1x3% | <input type="checkbox"/> 3x3% | <input type="checkbox"/> 3x6% |
| SAMPLE DESCRIPTION/FOAM TYPE: | | | |
| <input checked="" type="checkbox"/> AFFF | <input type="checkbox"/> AR-AFFF | <input type="checkbox"/> FFF | <input type="checkbox"/> HI-EX |
| <input type="checkbox"/> PROTEIN | <input type="checkbox"/> FFFP | <input type="checkbox"/> AR-FFFP | <input type="checkbox"/> FP |
| <input type="checkbox"/> OTHER: | | | |
| Please return your samples to: Oil Technics Foam Testing Services Linton Business Park, Gordon, Aberdeenshire, Scotland UK DD10 0NH T: +44 (0) 1561 361515 E: info@foamtesting.com W: foamtesting.com | | | |

Service Level:
☒ **STANDARD**
5-working days
from receipt of sample
☐ **EXPRESS**
24-hours
from receipt of sample

Notes:
For each test sample, please provide:
• 1 litre of Foam Concentrate
• 1 litre of Produced Foam
• 1 litre of Induction Water
Please also send with your sample:
• Foam Testing Request Form
• Foam Concentrate manufacturer's SDS (if available)

| SAMPLE FOR ANALYSIS: PRODUCED FOAM TEST | | | |
|---|---|--|-----------------------------|
| Produced Foam | | | |
| SAMPLE REFERENCE NO. (INTERNAL USE ONLY): | ORDER REF./P.O. NO.: 290924A | | |
| COMPANY NAME: ACME LTD | SAMPLE POINT: PORT FOAM | | |
| SAMPLE LOCATION: CITY REFINERY | | | |
| DATE OF COLLECTION: 26/09/2024 | | | |
| CONCENTRATION: | | | |
| <input type="checkbox"/> 1% | <input type="checkbox"/> 2% | <input checked="" type="checkbox"/> 3% | <input type="checkbox"/> 6% |
| <input type="checkbox"/> OTHER: | | | |
| INDUCTION WATER TYPE: | | | |
| <input type="checkbox"/> SEAWATER | <input checked="" type="checkbox"/> FRESH (POTABLE) | <input type="checkbox"/> BRACKISH | |
| <input type="checkbox"/> OTHER: | | | |
| Please return your samples to: Oil Technics Foam Testing Services Linton Business Park, Gordon, Aberdeenshire, Scotland UK DD10 0NH T: +44 (0) 1561 361515 E: info@foamtesting.com W: foamtesting.com | | | |

Service Level:
☒ **STANDARD**
5-working days
from receipt of sample
☐ **EXPRESS**
24-hours
from receipt of sample

Notes:
For each test sample, please provide:
• 1 litre of Foam Concentrate
• 1 litre of Produced Foam
• 1 litre of Induction Water
Please also send with your sample:
• Foam Testing Request Form
• Foam Concentrate manufacturer's SDS (if available)

| SAMPLE FOR ANALYSIS: PRODUCED FOAM TEST | | |
|---|---|-----------------------------------|
| Induction Water | | |
| SAMPLE REFERENCE NO. (INTERNAL USE ONLY): | ORDER REF./P.O. NO.: 290924A | |
| COMPANY NAME: ACME LTD | SAMPLE POINT: INLET A | |
| SAMPLE LOCATION: CITY REFINERY | | |
| DATE OF COLLECTION: 26/09/2024 | | |
| INDUCTION WATER TYPE: | | |
| <input type="checkbox"/> SEAWATER | <input checked="" type="checkbox"/> FRESH (POTABLE) | <input type="checkbox"/> BRACKISH |
| <input type="checkbox"/> OTHER: | | |
| Please return your samples to: Oil Technics Foam Testing Services Linton Business Park, Gordon, Aberdeenshire, Scotland UK DD10 0NH T: +44 (0) 1561 361515 E: info@foamtesting.com W: foamtesting.com | | |

Service Level:
☒ **STANDARD**
5-working days
from receipt of sample
☐ **EXPRESS**
24-hours
from receipt of sample

Notes:
For each test sample, please provide:
• 1 litre of Foam Concentrate
• 1 litre of Produced Foam
• 1 litre of Induction Water
Please also send with your sample:
• Foam Testing Request Form
• Foam Concentrate manufacturer's SDS (if available)



Step 4: Complete a Foam Testing Request Form

To make sure we are carrying out the testing you need, a completed Foam Testing Request Form is required.

A blank template can be downloaded from our website.

How to Get your Foam Tested:

Produced Foam Test



Step 5: Print a Safety Data Sheet

Include a copy of the foam concentrate manufacturer's safety data sheet along with your sample, if you have one.

If you don't have an SDS, make sure you include the foam manufacturer's name on your sample. Please note inclusion of an SDS is usually a shipping requirement.



Step 6: Package & Send

Package your labelled samples, Foam Testing Request Form and Safety Data Sheet, if available, in a suitable box or container and send it to us:

Oil Technics Foam Testing Services
Linton Business Park, Gourdon, Montrose,
Aberdeenshire, Scotland UK DD10 0NH

An address label template can be downloaded from our website. Need help with shipping? Contact us for more information.



Step 7: Testing & Report

On receipt of your sample, we'll get to work testing your foam.

We operate a standard 5-working day turnaround or offer an express 24-hour service. Your report will be emailed to you.



Checklist

To help make sure nothing has been missed for you to have your foam tested, please use the following checklist:

Information needed:

☐ **Correct testing selected**

ie Foam Concentrate, Produced Foam, IMO Foam Concentrate or PFAS TOP Assay testing

☐ **Service Level selected**

ie Standard Service: (5-working days turnaround from receipt of sample) or Express Service (24-hour turnaround from receipt of sample)

☐ **Correct amount of foam samples taken**

For each produced foam concentrate test sample, we require 1 litre of foam concentrate, 1 Litre of produced foam and 1 litre of induction water

☐ **Foam samples correctly labelled**

including foam type, sample location, foam concentration (%), etc

Documentation needed:

☐ **Foam Testing Request Form completed**

ensuring all required information is included

☐ **SDS printed**

if available. If you don't have an SDS, make sure you include the foam manufacturer's name on your sample.

Still not sure?

Get in touch and our team can help with any questions:

T: +44 (0) 1561 361515 **E:** info@foamtesting.com

